BX-ENEL5-1
Quick Start

## Package Checklist

The package includes the following items:
- One BX-ENEL5-1 Battery Box
- One Cable (4SCA024)
- One Quick Start

Related Documents
### Documents
- Quick Start: BX-ENEL5-1_QuickStart.pdf

➢ BX-ENEL5-1 Dimensions (Unit: mm)

Top View

Left Side View   Front View   Right Side View   Rear View

16   56   17.7   35.5   75   69.3   16.0   5.3

Bottom View   Unit: mm

➢ Cable Dimensions (Unit: mm)


150 ±15 mm

➢ Installation

A. Install Nikon a battery ENEL5 into the battery box.

B. Install BX-ENEL5-1 battery box and GT-530 (or other device that need the battery) on DIN Rail, and connect the connector of the battery to the slot "BAT" of GT-530.

➢ Technical Support

ICP DAS Service : **service@icpdas.com**